CONVEYORS

moodydirect

For calls outside the UK Telephone +44 1777 7(Telephone 701141 or Fax +44 1777 869983

FREEPHONE: 0800 666397

CONVEYOR COMPONENTS


We are now able to supply a full range of components to suit your conveyor. In addition we can offer a wide range of maintenance free polymer bearings featured within, some of which are ideally suited to conveyor maintenance.

Illustrated here is a selection of the components available.



LEVELLING PADS 3

- Thermoplastic, steel and stainless steel supporting feet.
- Fixed feet.
- Threaded tube ends.
- Articulated feet with or without mounting holes.
- Vibration absorbing feet.
- Support bases.



- corner discs.
- Chain return components.
- Adjustable heads and knobs.
- Side mounting and support heads.
- Threaded tube ends.
- Thermoplastic chains.
- Straight and corner tracks.
- Guide rail brackets and drip tray supports.

STRUCTURAL COMPONENTS 4

- Connecting joints.
- Panel clamps.
- Fixing block.
- Spring loaded latch.
- Tube ends and closing caps.
- Mounting profiles.
- Profile for plain tubes.
- Magnetic lock.
- Hinges and Handles

CONVEYOR COMPONENTS Drive sprockets, idler wheels,

- Lateral guides and guide rail clamps.

- Cross clamps.
- Hinges and handles.
- Support bases and levelling elements.

5 CONVEYOR CHAINS

- Straight running chains.
- Sideflexing chains magnetic system.

BEARING SUPPORTS

Flanged bearing support.

Cartridge/take-up support.

Flanged bearing support in

Support for shafts from Ø 12

Compact pillow block support.

Support with high corrosion resistance.

Pillow block support.

Take-up support.

to Ø 40 mm.

stainless steel.

Cartridge support.

2

- Sideflexing chains with rubber pads.
- Sideflexing chains.
- Straight running chains with rubber pads.
- Straight and corner tracks.



